

Skimmer

Ensure all Prestart checks have been carried out

Brush/Disk does not turn	
<i>*Never work on hydraulics under load.</i>	
Hydraulic hoses not connected	Correctly fit hydraulic hoses.
Hydraulic motor damaged	Repair replace hydraulic motor.
Waste not discharging	
Blockage	Ensure hoses and brushes/disks are free from obstruction.
Low hydraulic oil	Check and refill as necessary.
Worn brush/disks	Check and replace as necessary.

